

OMRON

Contact-Type Smart Amplifier (Detection Type)

E9NC-TA0

INSTRUCTION SHEET

Thank you for selecting an OMRON product. This sheet primarily describes precautions required in installing and operating the product.

- A specialist who has the knowledge of electricity must treat the product.
- Please read this manual carefully, and use it correctly after thoroughly understanding the product.
- Please keep this manual properly for future reference whenever it is necessary.

The following notice applies only to products that carry the CE mark : Notice :

This is a class A product. In residential areas it may cause radio interference, in which case the user may be required to take adequate measures to reduce interference.



© OMRON Corporation 2014 All Rights Reserved.

PRECAUTIONS ON SAFETY

● Meanings of Signal Words

WARNING Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.

● Warning Indications

WARNING

This product is not designed or rated for ensuring safety of persons either directly or indirectly. Do not use it for such purpose.

Do not use the product with voltage in excess of the rated voltage. Excess voltage may result in malfunction or fire.

Never use the product with an AC power supply. Otherwise, explosion may result.

PRECAUTIONS FOR SAFE USE

The following precautions must be observed to ensure safe operation of the product. Doing so may cause damage or fire.

- Do not install the product in the following locations.
 - (1) Locations subject to direct sunlight
 - (2) Locations subject to condensation due to high humidity
 - (3) Locations subject to corrosive gas
 - (4) Locations subject to vibration or mechanical shocks exceeding the rated values
 - (5) Locations subject to exposure to water, oil, chemicals
 - (6) Locations subject to steam
 - (7) Locations subjected to strong magnetic field or electric field
- Do not use the product in environments subject to flammable or explosive gases.
- Do not use the product in any atmosphere or environment that exceeds the ratings.
- To secure the safety of operation and maintenance, do not install the product close to high-voltage devices and power devices.
- Do not use the product if the case is damaged.
- Burn injury may occur. The product surface temperature rises depending on application conditions, such as the ambient temperature and the power supply voltage. Use caution when operating or cleaning the product.
- When setting the sensor, be sure to check safety such as by stopping the equipment.
- Be sure to turn off the power supply before connecting or disconnecting wires.
- Do not attempt to disassemble, repair, or modify the product in any way.
- When disposing of the product, treat it as industrial waste.
- Do not miswire such as the polarity of the power supply.
- Do not use on underwater, rain or the outdoors.
- Applicable standards
 - (1) EN61326-1
 - (2) Electromagnetic environment : Industrial electromagnetic environment (EN/IEC 61326-1 Table 2)

PRECAUTIONS FOR CORRECT USE

- Be sure to mount the unit to the DIN track until it clicks.
- To prevent electric shock or short circuit, put a protection cap (attached with Sensor communication unit E3NW) on unused connection power supply terminals.



- Do not apply excessive force such as tension, compression or torsion to the connector of the sensor head that is fixed to the amplifier unit.
- Always keep the protective cover in place when using the product. Not doing so may cause malfunction.
- It may take time until the received measured value become stable immediately after the power is turned on depending on use environment.
- The Mobile Console E3X-MC11, E3X-MC11-SV2 and E3X-MC11-S cannot be connected.
- Sensor communication unit E3NW-ECT/CCL can be used. E3X-DRT21-S, E3X-CRT/ECT and E3NW-CRT cannot be used.
- If you notice an abnormal condition such as a strange odor, extreme heating of the unit, or smoke, immediately stop using the product, turn off the power, and consult your dealer.
- Do not use thinner, benzene, acetone, and lamp oil for cleaning.

Checking the Package Content


- Amplifier Unit: 1
- Instruction Sheet (this sheet): 1 (Japanese, English and Chinese)

Compatible Communication Unit (Sold Separately)

E3NW Series Communication Unit, Distribution unit E3NW-DS

1 Installation

1-1 Dimensions



Dimensions in parentheses () indicates the ones with related components. Unit: mm
The cover could come off if it is tilted by 152 degrees or more.

1-2 Mounting the Amplifier Unit

■ Mounting on DIN Track


- (1) Let the hook on the Amplifier Unit's Sensor Head connection side catch the track.
- (2) Push the unit until the hook clicks into place.

■ Removing from DIN Track

- (1) Push the unit in the direction 1.
- (2) Lift the unit in the direction of arrow 2 while performing step (1).

■ Joining Amplifier Units


- (1) Mount the Amplifier Units one at a time onto the DIN track. Slide the Amplifier Unit until the communication connector is closely attached. (Arrow 3)
- (2) Use End Plates (PFP-M: separately sold) at the both ends of the grouped Amplifier Units to prevent them from separating due to vibration or other cause. (Arrow 4)
- (3) Tighten the screw on the End Plates using a driver. (Arrow 5)



For the maximum number of units that can be connected, refer to the specifications of each E3NW Series Communication Unit. Always use the End Plates.


1-3 Mounting the sensor head

1. Open the protection cover.
2. Insert the sensor head, with the lock lever on its connector area facing upward, all the way into the connector port. The color of the connector cover for E9NC-TH is yellow. Make sure to avoid misconnection by confirming the cover color in advance. To remove it, press and hold the lock lever then pull the sensor head out.



2 Settings

2-1 Setting and Display Overview




2-4 Smart Tuning

1. Press and hold the [Mode] button for 3 seconds or longer to enter the [Set Mode]. 2. Then Press and hold the [Mode] button for 3 seconds or longer to exit the [Set Mode]. *Refer to "⑤ Detailed Settings".

Setting for sensing within the range of the upper and lower limits

● 2-point area tuning


1. Select [Set Mode] → [Output Mode Selection] → [Area Sensing Mode].
 2. Press [S.TUNE] button at the upper limit Work, then press [S.TUNE] button again at the lower limit Work.
- Threshold value HIGH : Upper Limit Work Height
Threshold Value LOW : Lower Limit Work Height



Measuring a Work with ± tolerance

● Tolerance tuning


1. Select [Set Mode] → [Tolerance Setting : HIGH] and configure the tolerance value on the High end.
2. Select [Set Mode] → [Tolerance Setting : LOW] and configure the tolerance value on the Low end.
3. Select [Setting Mode] → [Output Mode Selection] → [Area Sensing Mode].
4. Press and hold [S.TUNE] button for 3 seconds or longer.



Measuring for one reference

● 2-point Tuning


1. Select [Set Mode] → [Output Mode Selection] → [Area Sensing Mode].
 2. Press [S.TUNE] button at the Work(1), then press [S.TUNE] button again at the Work(2).
- Threshold value setting: Set the value in the middle between the measured values for the 1st and 2nd points.



Measuring for standard Work as reference

● 1-point tuning

1. Select [Set Mode] → [Output Mode Selection] → [Area Sensing Mode].
 2. Press and hold [S.TUNE] button for 3 seconds or longer.
- Threshold setting: Set the Work value as the threshold.



● Smart Tuning Error

Error / Display / Cause	Error Origin Tuning Type	Remedy
Tuning Error EtUn Errr The 1st and the 2nd measuring points are close, or tolerance setting is too small.	2-point area tuning Tolerance tuning	• Ensure the wider distance between the 1st and the 2nd measuring points. • Set the larger difference between the tolerance settings of HIGH and LOW. • For hysteresis setting, configure a smaller setting value.
Near Error nERr Errr The difference between the 1st and the 2nd measured values is too small.	2-point Tuning	• Ensure the wider distance between the 1st and the 2nd measuring points. • For hysteresis setting, configure a smaller setting value.
Overflow Error auEr FLoY The preset or tolerance setting value is too large.	2-point area tuning Tolerance tuning 2-point Tuning 1-point Tuning	• Configure the preset value again. • Configure the tolerance setting again.
Underflow Error Undr FLoY The preset or tolerance setting value is too small.	2-point area tuning Tolerance tuning 2-point Tuning 1-point Tuning	• Configure the preset value again. • Configure the tolerance setting again.

2-2 Output switching

Press button.

Switches the polarity of the output.

Under NO (Normal Open) setting, the output turns ON when a Work is in the detection zone.

of [NO/NC Indicator] turns ON.

Under NC (Normal Close) setting, the output turns ON when a Work is not in the detection zone.

of [NO/NC Indicator] turns ON.


2-3 Origin Point

When origin point use setting is ON (See (3) Convenient Setting Features)

1. The measured value is not displayed until the sensor head passes the origin point after power ON.

2. To display the measured value, the sensor head must pass the origin point / the point the sensor head is pressed in by 1.5mm from where it is fully extended.












When you use the position of work, please set OFF of [Origin Point Use Setting].



2-5 Minute Adjustment of Threshold Level

1. Under [Detection Mode], press and hold button for 1 second.

2. The threshold value blinks.




Pressing and holding the button allows quick tuning. To manually set threshold values, always configure them so that "HIGH threshold value > LOW threshold value". If they are configured as "HIGH threshold value < LOW threshold value", GO judgment is not given regardless of a measured value.

- HIGH and LOW indicators turn ON at the same time and error output is provided.

3 Convenient Setting Features

Initializing Settings


- **Setting Reset** Initialize all settings to the factory-set defaults.



Saving/Reading Settings

- **User Save Function/User Reset**

User Save: The current settings are saved.
User Reset: The saved settings are loaded.



Using the sensor head origin point/Setting the point at power ON as origin

- **Origin Point Use Setting**

1. Select [Setting Mode] → [Origin Point Use Setting].
ON: The unit automatically waits for the origin point signal after power on. If the sensor head is pressed down by 1.5 mm or more to the upper direction and passes the origin point, a measured value is displayed that is based on the origin point as a reference.
OFF: The origin point is set as a position of the sensor head at power on, and the measured value is displayed. The displayed value is the preset value.
*After the setting, turning the power OFF then ON, or searching the origin point again, reflects the origin point use setting to measurement.
*When the origin point use setting is ON, a hyphen mark is displayed until the sensor head passes the origin point.

4 Maintenance

4-1 Troubleshooting

- **Troubleshooting**

Phenomena	Cause	Remedy
Nothing is shown on the indication.	Is the power supply ON? Are the cables not broken?	Check the wiring and sensor head, the power supply voltage and capacity.
The Sensor restarts during operation.		
Nothing is shown on the digital indication.	Is the Eco function not turned ON? Refer to "③ Convenient Setting Features".	Turn OFF the Eco function.
The measured value is not displayed in 0.0001 step	Have the display digits configured properly?	Select [Display Digits] to 0.0001. Refer to "⑤ Detailed Settings".
The judgment output is not properly provided	Have the tolerance setting and hysteresis properly configured?	Configure the tolerance setting and hysteresis properly. Refer to "⑤ Detailed Settings".
Lost tracking of the settings made.	—	Reset the settings. Refer to "③ Convenient Setting Features".

- **Error Display**


Error Name / Display	Cause	Remedy
Load short circuit detection error E-SL	The judgment output is short circuited.	Turn off the power supply, check whether the Communication Unit compatible wire-saving connector is short circuited or not, and then turn on the power supply again.
Overcurrent protection error E-Hd CUL	A connection error is found in the sensor head.	Check if the sensor head is correctly mounted and turn ON the power supply again.
Amp EEPROM error E-NE 01	An error is found in amp setting memory.	Turn on the power supply again. If the restoration fails, reset the settings.
E-NE 02		
Sensor head communications time-out error E-Hd Con I	A communications error is found between the sensor head and amp.	Turn OFF the power supply and check if the sensor head and amplifier unit are correctly connected and then turn ON the power supply again. If the error persists, the sensor head or amplifier unit are broken. Replace the sensor head or amplifier unit.
Sensor head memory error E-Hd NE n2	An error is found in sensor head setting memory.	Turn off the power, check the connection of the sensor head, and turn on the power again. If the error persists, the sensor head is out of order. Replace the sensor head.
Sensor head speed error E-Hd SPd	The speed of passing the origin point was too high.	Turn off the power, check that too much impact has not given to the sensor head.
Sensor head signal level error E-Hd Lu	The sensor head circuit failure	Turn off the power, check the connection of the sensor head, and turn on the power again. If the error persists, the sensor head is out of order. Replace the sensor head.

Preventing Malfunction

- **Key Lock** Disables all the button operations.




- **Origin point search again** (to capture the sensor head origin point again)



- **Preset**

Set any preset value for the criteria position and perform measurement and judgment output. The preset value on factory shipment is 0, which can be used for zero-resetting.



- **Status Display**

Error Name / Display	Cause	Remedy
Lock ON LoC on	The key lock function enabled	Cancel the key lock function. Refer to "③ Convenient Setting Features"
Measured value upper limit error .ouEr	The measured value is over the display upper limit (9999.9999).	Review the preset value.
Measured value lower limit error .Lo	The measured value is under the display lower limit (-1999.9999).	Review the preset value.
Moving average count unreached -----	The measured values for the number of moving average count is being acquired from the sensor head.	Please wait until the moving average result is calculated
Origin point not acquired -----	The sensor head did not pass the origin point.	Have the sensor head pass the origin point (the point the sensor head is pressed in by 1.5 mm from where it is fully extended).



4-2 Ratings and Specifications

Model	E9NC-TA0
Control output	2
Display resolution	Minimum 0.1 μm
Connection method	Communication Unit compatible wire-saving connector
Power supply voltage	Supplied from the connector through the communications units.
Power consumption	Power supply voltage 24V: Normal mode: 2040mW max. (Power consumption 85mA max.) Eco function ON: 1800mW max. (Power consumption 75mA max.) Eco function LO: 1920mW max. (Power consumption 80mA max.)
Control output	Please refer to the specification of a communication unit.
Protection circuit	Power supply reverse polarity protection, output short-circuit protection
Ambient temperature range	Operating: 1 to 2 amplifiers connected: 0°C to 55°C, 3 to 10 amplifiers connected: 0°C to 50°C, 11 to 16 amplifiers connected: 0°C to 45°C, 17 to 30 amplifiers connected: 0°C to 40°C Storage: -30°C to 70°C (with no icing or condensation)
Ambient humidity range	Operating and storage: 35% to 85% RH (with no condensation)
Insulation resistance	20 MΩ min. (at 500 VDC)
Dielectric strength	1,000 VAC, 50/60 Hz, 1 minute
Vibration resistance	10 to 55 Hz with a 1.5-mm double amplitude for 2 hrs each in X and Y directions
Shock resistance	150 m/s ² , for 3 times each in X, Y and Z directions
Weight (packed state/sensor)	Approx. 65 g/Approx. 25 g
Materials	Case and cover: Polycarbonate (PC)

5 Detailed Settings

Hold **MODE** button for 3 seconds or longer to enter SET mode.

SET mode provides the function settings described hereafter. The initial display shown after transition from one function to another represents the factory default.



Suitability for Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM. See also Product catalog for Warranty and Limitation of Liability.

OMRON Corporation	Industrial Automation Company
Tokyo, JAPAN	Contact: www.ia.omron.com
Regional Headquarters	
■ OMRON EUROPE B.V. Sensor Business Unit Carl-Benz-Str. 4, D-71154 Nufringen, Germany Tel: (49) 7032-811-0/Fax: (49) 7032-811-199	
■ OMRON ELECTRONICS LLC 2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787	
■ OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711	
■ OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200	

D ⑤ Oct, 2014

使用说明书

感谢您购买本产品，谨致谢意。
使用时请务必遵守以下内容。
• 请具备电气知识的专业人员实施操作。
• 请在阅读并理解本说明书的基础上正确使用。
• 请妥善保管本说明书，以备随时查阅。

欧姆龙公司

© OMRON Corporation 2014 All Rights Reserved.

安全注意事项

● 警告标识的含义

警告 若使用不当，则有可能对人身造成轻度或中度伤害，或造成经济损失。

● 警告标示

警告

请勿出于安全目的将本产品直接或间接使用在人体检测用途上。
也勿使用在人体保护用的检测装置上。



可能会引起故障或火灾。
使用时，请勿超过额定电压。



可能会导致产品破裂。
严禁在AC电源下使用。




安全要点

- 为了确保您的安全，请务必遵守以下内容。否则可能会引起损坏或火灾。
- 请勿在以下环境中使用。
 - ①阳光直射的场所
 - ②湿度高、易结露的场所
 - ③有腐蚀性气体的场所
 - ④振动或冲击超出额定范围的场所
 - ⑤有水、油、化学药品等飞溅的场所
 - ⑥接触到蒸汽的场所
 - ⑦强电场、强磁场的场所
 - 请勿在有易燃、易爆气体的环境下使用。
 - 请勿在超出额定范围的环境下使用。
 - 请将传感器设置在远离高压或动力设备的地方，以免操作或维护时发生危险。
 - 请勿在外壳破损的状态下使用。
 - 可能会导致烫伤。根据使用条件（环境温度、电源电压等）不同，传感器表面温度会升高，因此在操作或清洁时请多加注意。
 - 设定传感器时请停止装置运行，确认安全后再执行操作。
 - 请务必切断电源后再安装或拆卸导线。
 - 请勿擅自拆卸、修理、改造本产品。
 - 废弃时，请作为工业废弃物处理。
 - 请注意电源的极性，防止错误接线。
 - 请勿在水中、降雨中以及屋外使用。
 - 对应规格
 - ①EN61326-1
 - ②Electromagnetic environment : Industrial electromagnetic environment (EN/IEC 61326-1 Table 2)

使用注意事项

- 安装至 DIN 导轨时，请推压放大器直至钩爪完全嵌入导轨。
- 为了防止触电或短路，请在不使用的电源连接端子上，盖上保护盖。（附属于型号 E3NW 系列传感器通信单元）



- 光纤固定于放大器状态下，请勿对其强行施加拉伸力、压缩力、扭转力等。
- 请务必安装保护罩后使用。可能会导致错误操作。
- 接通电源后，由于周围环境不同，到测定值安定为止可能需要一定时间。
- 无法连接手持式控制器型号 E3X-MC11、E3X-MC11-SV2、E3X-MC11-S。
- 可以连接通信单元型号 E3NW-ECT/CCL，但无法连接型号 E3X-DRT21-S、E3X-CRT、E3X-ECT、E3NW-CRT。
- 万一感觉异常时，请立即切断电源停止使用，并联系本公司或代理商。
- 请不要使用稀释剂，苯，丙酮或煤油类清洁。

包装内容确认


- 放大器 1 台
- 使用说明书（本说明书）日语、英语、中文各 1 份。

支持通信单元（另售）

E3NW 系列通信单元，分散单元型号 E3NW-DS

1 设置

1-1 外形尺寸图



单位: mm

1-2 放大器的安装

■ 安装至 DIN 导轨

- 如右图所示，将探头插入入口一侧的钩爪嵌入导轨。
- 往后下方推压放大器，直至钩爪完全锁定。

■ 从 DIN 导轨上拆卸

- 如右图所示，将放大器往方向 1 推压。
- 同时朝方向 2 提起。

■ 并排使用时


- 将放大器逐一安装至 DIN 导轨上，靠近并锁紧各台放大器。（方向 3）
- 若要防止因震动而导致的产品移位，请另行购买边缘导轨(型号 PFP-M)来固定放大器。（方向 4）
- 请用螺丝刀固定边缘导轨上的螺钉。（方向 5）

最多可连接台数请查看各 E3NW 系列通信单元的规格。
请务必使用终端架。

1-3 探头的安装


- 打开保护罩。
- 如右图所示，将探头的锁定拨杆面朝上，插入放大器连接器插口的最底部。E9NC-TH 是黄色连接器保护套，请注意安装时不要误接。

拆卸方法为，一边按住锁定拨杆一边向外拔出。



2 设定

2-1 操作・显示一览表




2-4 智能调整

设定放大器时，长按 [MODE] 按钮 3 秒以上，方可进入 [设定模式]。
在设定模式下，长按 [MODE] 按钮 3 秒以上，方可回到 [检测模式]
在工件上下限范围内检测的设定

● 两点区域示教

- 选择 [设定模式]→[判定输出模式]→[区域检测模式]。
- 上限工件时按 [S.TUNE] 按钮，下限工件时再按 [S.TUNE] 按钮。

阈值 HIGH: 上限工件高度
阈值 LOW: 下限工件高度




想要以相对工件的 ± 公差进行测定时

● 公差调整

- 选择 [设定模式]→[公差设定: HIGH], 设定 High 侧的公差数值。
- 选择 [设定模式]→[公差设定: LOW], 设定 Low 侧的公差数值。
- 选择 [设定模式]→[判定输出模式]→[区域检测模式]。
- 长按 [S.TUNE] 按钮 3 秒以上。


阈值 HIGH: 预设值+公差设定 (HIGH)
阈值 LOW: 预设值-公差设定 (LOW)



针对 1 个基准进行测定时

● 两点示教


- 选择 [设定模式]→[判定输出模式]→[区域检测模式]。
- 工件①时按 [S.TUNE] 按钮一次，工件②时再按 [S.TUNE] 按钮一次。



以标准工件为基准进行测定时

● 一点示教

- 选择 [设定模式]→[判定输出模式]→[区域检测模式]。
- 长按 [S.TUNE] 按钮 3 秒以上。



● 智能调整错误

错误名称 / 显示 / 原因	调整类型	对策
tunning error EtUn Err 第 1 点和第 2 点过于接近、或公差设定的差值过小的状态。	两点区域示教 公差调整	• 请扩大第 1 点和第 2 点的测定位置间距。 • 请增大公差设定 HIGH、LOW 之间的差值。 • 设定磁滞幅度时，请减小小设定值。
Near Error nERr Err 第 1 点和第 2 点的测定值差过小的状态。	两点示教	• 请扩大第 1 点和第 2 点的测定位置间距。 • 设定磁滞幅度时，请减小小设定值。
Overflow Error auEr FLoY 预设值或公差设定值过大。	两点区域示教 公差调整 两点示教 一点示教	• 请重新设定预设值。 • 请重新设定公差设定值。
Underflow Error Undr FLoY 预设值或公差设定值过小。	两点区域示教 公差调整 两点示教 一点示教	• 请重新设定预设值。 • 请重新设定公差设定值。

2-2 输出切换方法

●


键进行设定。
切换输出的极性。
若设定为 NO (NormalOpen)，则在检测区域内有工件时输出 ON。
[NO/NC 指示灯] 的 **NO** 亮灯。
若设定为 NC (NormalClose)，则在检测区域内无工件时输出 ON。
[NO/NC 指示灯] 的 **NC** 亮灯。

2-3 关于原点

使用原点设定为 ON 时 (参照③ 便利的设定章节)

- 接通电源后，在探头通过原点之前不显示测定值。
- 为显示测定值，需使探头通过原点 (探头由完全伸出状态至被推回 1.5mm 处)。

若想在不过原点的位置使用，请把使用原点设定设置为 OFF，在使用。



设定完毕


设定完毕

设定完毕

设定完毕

2-5 阈值的微调

- 在 [检测模式] 下持续按 **GO** 按钮 1 秒种。
- 阈值即会显示闪烁状态。
《设定区域输出模式时》
• LOW 阈值显示




●

可持续按按钮进行高速调整。通过手动方式设定阈值时，请务必设定为“HIGH 阈值<LOW 阈值”状态。
若设定为“HIGH 阈值<LOW 阈值”状态，
• 无论测定值如何，均不会执行 GO 判定。
• 判定结果为 HIGH/LOW 以外状况时，HIGH 指示灯及 LOW 指示灯将会同时亮灯，并输出错误。

3 便捷设定

设定初始化


- 设定初始化 把设定状态初始化，恢复出厂时状态。



保存 / 读取设定

- 保存 / 读取设定

设定保存：保存当前的设定。
设定重置：保存当前的设定。



想要使用探头原点 / 想要将电源 ON 时的位置作为原点时


- 使用原点设定

1. 选择 [设定模式]→[使用原点设定]。
ON 时：接通电源后，自动进入等待原点信号状态。将探头向上推向 1.5mm 以上使其通过原点，则会显示以探头原点为基准的测定值。
OFF 时：将接通电源时的探头位置作为原点，显示测定值。这种情况下所显示的数值为预设值。
※设定后，通过电源的 OFF/ON 切换或原点再搜索，使用原点设定即会反映在测定中。
※使用原点设定为 ON 时，在通过探头原点前显示连字符。

防止误操作

- 按键锁定 关闭所有按钮的操作功能。

开启 / 解除 (步骤相同)



- 原点再搜索 (想要重新获取探头原点时)



1. 持续同时按 [MODE]+[NO/NC] 按钮 3 秒以上。
※使用原点设定为 ON 时：未获取原点状态 (连字符)。请使探头通过其原点。
使用原点设定为 OFF 时：按预设值调整执行时的位置。

- 预设功能

在对基准位置设定任意预设值后，执行测定值及判定输出。
出厂时所设定的预设值为 0，可作为归零重置使用。

开启



解除



开启

1. 选择 [设定模式]→[输入预设值]，设定任意数值

长按 [MODE] 键 3 秒以上退出设定模式。

2. 在 [检测模式] 下持续同时按 [STUNE]+[UP] 按钮 3 秒以上。

解除

1. 在 [检测模式] 下持续同时按 [STUNE]+[DOWN] 按钮 3 秒以上。

※使用原点设定为 ON 时，基准位置信息将被保存，因此，即使切断电源，重新接通后依然可恢复基准位置。

※预设值可在 -1999.9999 ~ 9999.9999 的范围内进行设定。(0.0001 刻度、初始值 0)

4 维修保养

4-1 故障排除

- 故障排除

故障	原因	对策
画面上无任何显示	节电功能是否为 ON 状态？	请重新配线探头、确认电源电压及电源容量。
会在运行中重启	节电功能是否为 ON 状态？	请关闭节电功能。 ⑤ 详细设定
没有任何数字显示	节电功能是否为 ON 状态？	⑤ 详细设定
测定值未以 0.0001 的单位显示	显示位数的设定是否正确？	请正确设定。 ⑤ 详细设定
判定输出不能正确执行	公差设定值、磁滞幅度的设定是否正确？	请正确设定公差设定值、磁滞幅度。 ⑤ 详细设定
设定状态不明	—	请执行设定初始化 ③ 便捷设定

- 维修保养的错误代码

错误名 / 显示	原因	对策
负荷短路检测错误 E-St	判定输出发生短路	请先切断电源，并确认通信单元专用连接器是否短路后再重新接通电源。
过电流保护错误 E-Hd CU-	探头连接异常	请确认探头是否正确安装后再重新接通电源。
放大器EEPROM错误 E-NE 01 E-NE 02	放大器设定存储异常	请重新接通电源。 若无法恢复，请执行设定初始化。
探头通信超时错误 E-Hd Con !	放大器和探头间通信异常	请先切断电源，并确认探头及放大器单元是否正确连接后再重新接通电源。若依然无法解决错误问题，则可能是探头或放大器单元发生故障。 请更换探头或放大器单元。
探头存储器错误 E-Hd NE NE2	探头设定存储异常	请先切断电源，并确认探头连接正确后，再重新接通电源。若依然无法解决错误问题，则可能是探头发生故障。请更换探头。
探头速度错误 E-Hd SPD	通过原点时的速度过快。	请确认是否对探头施加了过度的冲击力。 ③ 便捷设定
探头信号电平错误 E-Hd Lu	探头电路故障。	请先切断电源，并确认探头连接正确后，再重新接通电源。若依然无法解决错误问题，则可能是探头发生故障。请更换探头。

- 状态显示

错误名 / 显示	原因	对策
LOCK ON LoL on	开启了按键锁定功能	请关闭按键锁定功能 ③ 便捷设定
测定值上限错误 ouEr	测定值超出显示上限 (9999.9999)。	请重新设定预设值。
测定值下限错误 Lo	测定值低于显示下限 (-1999.9999)。	请重新设定预设值。
未达到移动平均次数状态 -----	正在通过探头获取移动平均次数的测定值。	请等待算出移动平均结果
未获取原点状态 -----	探头未通过原点。	请使探头通过原点 (探头由完全伸出状态至被推回 1.5mm 处)。

4-2 额定/规格



型号	E9NC-TA0
控制输出数	2
显示分辨率	最小 0.1μm
连接方式	通信单元专用连接器型
电源电压	通过连接器，由通信单元供给
电源电压	电源电压 24V 时常规模式：2040mW 以下 (消费电流 85mA 以下) 节电功能 ON：1800mW 以下 (消费电流 75mA 以下) 节电功能 LO：1920mW 以下 (消费电流 80mA 以下)
控制输出	请参考通信单元的规格
保护电路	电源逆接保护、输出短路保护
使用环境温度	动作状态：(1~2 台连接) 0℃ ~ +55℃、(3~10 台连接) 0℃ ~ +50℃、 (11~16 台连接) 0℃ ~ +45℃、(17~30 台连接) 0℃ ~ +40℃ 保存状态：-30℃ ~ +70℃ (无结冰凝露)
使用环境湿度	动作和保存状态：35~85%RH (无结冰凝露)
绝缘电阻	20MΩ 以上 (使用 DC500V 兆欧表)
耐电压	AC1,000V 50/60Hz 1min
振动 (耐久)	10 ~ 55Hz 双振幅 1.5mm X、Y、Z 各方向 2h
冲击 (耐久)	150m/s ² X、Y、Z 各方向 3 次
重量 (捆包 / 净重)	约 65g/ 约 25g
材质	外壳、保护罩：聚碳酸酯 (PC)

5 详细设定

长按 键 3 秒以上进入设定模式。

设定模式下可设置以下功能。

在主轴上显示的功能为出厂时的设定。



承诺事项

本公司产品是作为工业通用品而设计制造的。因此，不适用于以下用途，当本公司产品被使用于以下用途时，本公司不做任何保证。但若是本公司特意以为以下用途而设计、或有过特别协商的情况下，可以用于以下用途。

- 需要高度安全性的用途 (例：用于原子能控制设备、焚烧设备、航空・宇宙设备、铁道设备、升降设备、娱乐设备、医用器、安全装置、或其他可能危及到生命・人身安全的用途)
- 需要高可靠性的用途 (例：煤气・水力・电力等的供给系统、24 小时连续运转系统、决策系统、或其他牵涉到权利・财产的用途)
- 苛刻条件或环境下的用途 (例：室外设备、易受化学污染的设备、易受电磁干扰的设备、易受震动・冲击的设备等)
- 产品手册里未记载的条件或环境下的用途

*除上述 a)~d) 的记载事项，本产品手册等记载的商品不适用于机动车 (包括两轮车，以下相同)。请勿搭载于机动车上使用。机动车搭载用商品请咨询本公司销售人员。

*以上是适用条件的一部分。详情请参阅记载于本公司最新版的综合产品目录、使用手册上的保证・免责事项后再使用。

■ 技术咨询

欧姆龙 (中国) 有限公司
地址：中国上海市浦东新区银城中路 200 号
中银大厦 2211 室
电话：(86) 21-5037-2222
技术咨询热线：400-820-4535
网址：http://www.fa.omron.com.cn