
Star-Delta Timer With Free Power, Compact Size W38×H42mm


Features

- - : 100-240VAC 50/60Hz, 24-240VDC universal
- Wide time setting range and switching time
- T1 (setting time): selectable 0.5 to 100 sec
- T2 (switching time): selectable 0.05, 0.1, 0.2, 0.3, 0.4, 0.5 sec
- Close and DIN rail mounting with the dedicated socket (PS-M8) width 41mm
- Easy mounting and installation/maintenance with the dedicated bracket for DIN 48×48mm
- Application: Starting large capacity motors





■ Ordering Information



**8-pin socket (PG-08, PS-08(N), PS-M8) is sold separately.


Specifications

Function						
		Star-Delta Timer				
Control time setting range*1		0.5 to 100sec				
Power supply		100-240VAC ~ 50/60Hz, 24-240VDC== universal				
Allowable voltage range		90 to 110% of rated voltage				
Power consumption		Max. 3VA (100-240VAC∼), Max. 1.5W (24-240VDC≔)				
Return time		Max. 100ms				
Timing operation		Power ON Start				
Control	Contact type	Ա contact: SPST (1a), Δ contact: SPST (1a)				
output (Contact capacity	250VAC~ 3A, 30VDC= 3A resistive load				
Relay	Mechanical	Min. 10,000,000 operations				
life cycle	Electrical	Min. 100,000 operations (250VAC 3A resistive load)				
Repeat error		Max. ±0.2% ±10ms				
人 setting error		Max. ±5% ±50ms				
Voltage error		Max. ±0.5%				
Temperature error		Max. ±2%				
人 -∆ switching time error		Max. ±25%				
Insulation resistance		Over 100MΩ (at 500VDC megger)				
Dielectric strength		2,000VAC 50/60Hz for 1 min				
Noise immunity		±2kV the square wave noise (pulse width 1µs) by noise simulator				
Vibration	Mechanical	0.75mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 1 hour				
Vibration	Malfunction	0.5mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 10 min				
Shock	Mechanical	300m/s² (approx. 30G) in each X, Y, Z direction 3 times				
SHOCK	Malfunction	100m/s² (approx. 10G) in each X, Y, Z direction 3 times				
Environ-	Ambient temp.	-10 to 55°C, storage: -25 to 65°C				
ment /	Ambient humi.	35 to 85%RH, storage: 35 to 85%RH				
Approval		20 (((((((((((
Accessory		Bracket				
Unit weight		Approx. 72g				

K-52

Compact Star-Delta Analog Timer

Connections



SOURCE: 100-240VAC 50/60Hz, 24-240VDC universal

Dimensions


(unit: mm)

•Panel cut-out


Min. 55


45^{±6}

45 +0.6




Bracket





Unit Description



(A) Photoelectric Sensors

(B) Fiber Optic Sensors

> (C) Door/Area Sensors

> (D) Proximity Sensors

(E) Pressure Sensors

(E)

Rotary Encoders

(G) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(H) Temperature Controllers

(I) SSRs / Power Controllers

(J) Counters

(K) Timers

> L) Panel Meters

(M) Tacho / Speed / Pulse

>) splay

O) Sensor

(P)

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

(R) Graphic/ Logic Panels

Field Network Devices

(T) Software

Autonics K-53

■ Time Specifications


1. T1 (setting time) time

Time range	Time unit	Time setting range		
5		0.5 to 5sec		
10	SEC	1 to 10sec		
50		5 to 50sec		
100		10 to 100sec		

2. T2 (从 -∆ switching time) time


(unit: sec)

Switching time display part	0.05S	0.18	0.28	0.38	0.48	0.5S
T2 (λ -Δ switching time)	0.05	0.1	0.2	0.3	0.4	0.5



Operation

When power is applied, λ contact will be ON. When reaching to T1 setting time, λ contact will be OFF and Δ contact will be ON after switching time of T2 is passed. If the power is OFF, λ contact will be OFF.




XT1: setting time (λ contact operation time)

 \times T2: λ - Δ switching time (λ contact and Δ contact are OFF simultaneously at power ON)

■ Proper Usage

- Please supply power quickly at once with using switch or relay contact. Otherwise it may cause time error or power reset failure.
- When supplying power for a long time, timer life cycle may be shorten due to overheat of inner components of timer.
- When supplied power of timer is DC, be sure that the polarity.
- When supplying the power to the timer, connection shown in (Figure 1) might cause malfunction due to leakage current through R and C. Please connect R and C as shown in (Figure 2) to prevent malfunction.



- Change the setting time (T1), time range or switching time (T2). Otherwise, it might cause malfunction if changing the setting time (T1), time range or switching time (T2) during operation.
- Do not use this unit at below places.
- Place where temperature or humidity is out of the rated specifications.
- Place where there is condensation by temperature changes.
- Place where there is flammable gas or corrosive gas.
- Place where there is dust, oil or severe vibration or impact.
- · Place where strong alkalis or acids is used.
- · Place where there is direct ray of the sun.
- Place where strong magnetic field or electric noise is generated.

K-54