

RL3/RL4/RL3e/RL4e

Connector Door Replacement ■ ■ ■

Removal:



This procedure should only be performed by a qualified service technician.

1. Remove any cables from the printer.
2. With the printer bottom side up, remove the old Connector Door by removing the two screws securing it to the printer.



Installation: *(reverse of removal, refer to the previous illustration if necessary)*

1. With the new Connector Door in position, reinstall the two previously removed screws.
 - If additional parts are required, reference Replacement Part No.: DPR78-2939-01 (5 pk): Cable Door, Over-Mold, RL.
Contact Datamax-O'Neil Customer Service for further details.
For further details regarding parts availability and where to buy, contact Datamax-O'Neil by Honeywell Customer Service.

No Liability for Negligent Use

In no event shall Datamax-O'Neil be held liable for any damages whatsoever (including, without limitations, damages for loss of profits, business interruption, loss of information, or other pecuniary loss) arising out of negligence in use and care of the product.